

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>32 Bits DRAM</u>	*256Kx32_Bits	LP-DRAM-72SIMM
	*1Mx32_Bits	LP-DRAM-72SIMM
	*2Mx32_Bits	LP-DRAM-72SIMM
	*4Mx32_Bits	LP-DRAM-72SIMM
<u>36 Bits DRAM</u>	*256Kx36_Bits	LP-DRAM-72SIMM
	*1Mx36_Bits	LP-DRAM-72SIMM
	*2Mx36_Bits	LP-DRAM-72SIMM
	*4Mx36_Bits	LP-DRAM-72SIMM
<u>8 Bits DRAM</u>	*256Kx8_Bits	LP-DRAM MODULE TESTER
	*1Mx8_Bits	LP-DRAM MODULE TESTER
	*4Mx8_Bits	LP-DRAM MODULE TESTER
<u>9 Bits DRAM</u>	*256Kx9_Bits	LP-DRAM MODULE TESTER
	*1Mx9_Bits	LP-DRAM MODULE TESTER
	*4Mx9_Bits	LP-DRAM MODULE TESTER

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>AKM</u>	AK93C45	
	AK93C45L	
	AK93C46	
	AK93C65	
	AK93C65L	
	AK93C67	
	AKM6264AP	
	AKM6264ASP	
	AKM6264ALP	
	AKM6264LP	
	AKM62256P	
	AKM62256LP	
	AKM62256LFP	
	AKM628128P	
	AKM628128LP	
	AKM628128FP	
	AKM628128LFP	
	AK6420H	
<u>ALTERA</u>	EP610	
	EP610I	
	EPC1PC8	
	*EPC1LC20	LP-PLCC-EPC1064
	EPC1064PC8	
	EPC1064VPC8	
	EPC1213PC8	
	*EPC1064LC20	LP-PLCC-EPC1064
	*EPC1064VLC20	LP-PLCC-EPC1064
	*EPC1213LC20	LP-PLCC-EPC1064
	*EPM7032	LP-PLCC-7032LC44
	*EPM7064LC44	LP-PLCC-7064LC44
	EPM7032S44(C)	LP-PLCC-7032S-44
	EPM7032S44(S)	LP-PLCC-7032S-44
	EPM7064S44(C)	LP-PLCC-7032S-44
	EPM7064S44(S)	LP-PLCC-7032S-44
	*EPM7064LC68	LP-PLCC-7064LC68
	*EPM7064LC84	LP-PLCC-7064LC84
	*EPM7064QC100	LP-QFP-7064QC100
	*EPM7096LC68	LP-PLCC-7096LC68
	*EPM7096LC84	LP-PLCC-7096LC84
	*EPM7128ELC84C	LP-PLCC-7128ELC84
	*EPM7128ELC84E	LP-PLCC-7128ELC84
	*EPM7160ELC84C	LP-PLCC-7160ELC84
	*EPM7160ELC84E	LP-PLCC-7160ELC84
<u>AMD</u>	AmPAL16L8-5	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	AmPAL16R4-5	
	AmPAL16R6-5	
	AmPAL16R8-5	
	AmPAL16L8-7	
	AmPAL16R4-7	
	AmPAL16R6-7	
	AmPAL16R8-7	
	AmPAL16L8H-10	
	AmPAL16R4H-10	
	AmPAL16R6H-10	
	AmPAL16R8H-10	
	PAL16L8D/2	
	PAL16R4D/2	
	PAL16R6D/2	
	PAL16R8D/2	
	PALCE16V8H	
	PALCE16V8Q	
	PALCE16V8Z	
	PALCE610H	
	PALLV16V8	
	PALCE20V8H	
	PALCE20V8Q	
	PALCE16V8H-7	
	PALCE16V8H-10	
	PALCE20V8H-7	
	PALCE20V8H-10	
	AmPALC22V10	
	PALCE22V10H	
	PALCE22V10Q	
	PALCE22V10-10	
	PALLV22V10Z	
	Am2716	
	Am2716B	
	Am9716	
	Am2732	
	Am2732A	
	Am2732B	
	Am2764	
	Am2764A	
	Am27C64	
	Am9764	
	Am27128	
	Am27C128	
	Am27256HV	
	Am27256	
	Am27C256	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	Am27H256	
	Am27512	
	Am27512HV	
	Am27C512	
	Am27C513	
	Am27C010	
	Am27H010	
	Am27HB010	
	Am27LV010	
	Am27C100	
	Am27C020	
	Am27LV020	
	Am27C040	
	Am27C080	
	Am27C400	
	Am27C1024	
	Am27C2048	
	Am27C4096	
	Am28F256	
	Am28F512	
	Am28F010	
	Am28F010A	
	Am28F020	
	Am28F020A	
	Am29F002B	
	Am29F002BB	
	Am29F002BT	
	Am29F002NB	
	Am29F002NBB	
	Am29F002NBT	
	Am29F002NT	
	Am29F002T	
	*Am29LV004B	LP-TSOP-29LV004/LV008
	Am29LV004BT	
	Am29LV004BB	
	*Am29LV008B	LP-TSOP-29LV004/LV008
	*Am29F010	LP-PLCC-1M32,LP-TSOP-32PIN
	*AM29F010A	LP-PLCC-1M32,LP-TSOP-32PIN
	*Am29F040	LP-PLCC-1M32,LP-TSOP-32PIN
	*AM29F040B	LP-PLCC-1M32,LP-TSOP-32PIN
	*Am29LV040B	LP-PLCC-1M32,LP-TSOP-32PIN
	*Am29F080	LP-TSOP-2XF008
	*Am29F080B	LP-TSOP-2XF008
	*Am29F016	LP-TSOP-29F016
	*Am29F100B-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F100T-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	*Am29F200B-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F200T-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F400AB-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F400BB-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F400AT-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F400BT-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F800B-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F800T-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F800BT	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29F800BB	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29LV400B-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29LV400T-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29LV400BB	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29LV400BT	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29DL800BB	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29DL800BT	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29LV800BB	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29LV800BT	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29LV800B-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*Am29LV800T-EC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*AM29LV160BT	LP-TSOP-2XFX00A
	*AM29LV160BB	LP-TSOP-2XFX00A
	*AM29LV160DB	LP-TSOP-48-2XFX00A
	*AM29LV160DT	LP-TSOP-48-2XFX00A
	*AM29LV160BT(SOP)	LP-PSOP-28F400
	*AM29LV160BB(SOP)	LP-PSOP-28F400
	27S12	
	27S13	
	27S18	
	27S19	
	27S20	
	27S21	
	27S28	
	27S29	
	27S32	
	27S33	
	27S41	
	27PS41	
	27S43	
	27S180	
	27S181	
	27S184	
	27S185	
	27S190	
	27S191	
	27S280	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	27S281	
	8751H	
	8753H	
	87C51	
	87C521	
	87C541	
	Am9128	
	Am99CL88	
	*MACH-110	LP-PLCC-MACH110
	*MACH-111	LP-PLCC-MACH110
	*MACH-210	LP-PLCC-MACH110
	*MACH-211	LP-PLCC-MACH110
	*MACH-215	LP-PLCC-MACH110
	*MACH-130	LP-PLCC-MACH130
<u>AMI</u>	18CV8	
	20CG10	
	22CV10	
<u>AMIC</u>	A275308	
	A276308	
	A277308	
	A278308	
<u>ASAHI-KASEI</u>	AK28C64	
<u>ASI</u>	27C256	
	27C512	
	27C010	
<u>AT&T</u>	ATT7C185P	
	ATT1736A	
	ATT1765A	
	ATT17128A	
<u>ATC</u>	ATC24LC02	
	ATC24LC02W	
	ATC24C04P	
	ATC93C46	DIP,LP-SOP-16PIN
	ATC93C56	DIP,LP-SOP-16PIN
	ATC93C66	DIP,LP-SOP-16PIN
	ATC93LC46	DIP,LP-SOP-16PIN
	ATC93LC46	DIP,LP-SOP-16PIN
	ATC93LC46	DIP,LP-SOP-16PIN
<u>ATMEL</u>	ATF16V8B/BL	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	ATF16V8BQ/BQL	
	ATF16V8C	
	ATF16V8CZ	
	AT17C65	
	AT17C128	
	AT17C256	
	ATF20V8B/BL	
	ATF20V8BQ/BQL	
	AT22V10	
	AT22V10B-10	
	AT22V10L	
	ATF22V10B/BL	
	ATF22V10BQ/BQL	
	AT24C01	
	AT24C01A	
	AT24C02	
	AT24C04	
	AT24C08	
	AT24C16	
	AT24C21	
	AT24C32	
	AT24C64	
	AT24C128	
	AT24C164	
	AT45DB081	
	AT27C64	
	AT27HC64	
	AT27C256	
	AT27C256R	
	AT27HC256	
	AT27LV256	
	AT27C512	
	AT27C512R	
	AT27LV512	
	AT27LV512R	
	AT27C513	
	AT27C513R	
	AT27BV010	
	AT27C010	
	AT27C010L	
	AT27LV010	
	AT27BV020	
	AT27C020	
	AT27LV020	
	AT27BV040	
	AT27C040	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	AT27LV040	
	AT27C080	
	AT27LV080	
	AT27HC641	
	AT27HC641R	
	AT27HC642	
	AT27HC642R	
	AT27C1024	
	AT27HC1024	
	AT27LV1024	
	AT27BV1024	
	AT27C2048	
	AT27C4096	
	AT27LV4096	
	AT28C04	
	AT28C16	
	AT2817A	
	AT28C17	
	AT2864A	
	AT28C64	
	AT28HC64	
	AT28C64B	
	AT28HC64B	
	AT28LV64B	
	AT28BV64	
	AT28HC191	
	AT28HC191L	
	AT28HC291	
	AT28HC291L	
	AT28C256	
	AT28HC256	
	AT29C256	
	AT29LV256	
	AT29C257	
	AT29C512	
	AT29LV512	
	AT29C010	
	AT29C010A	
	AT29LV010A	
	AT29LV1024	
	AT29C1024	
	AT29C010A-B	
	AT29C010A-T	
	AT29C020	
	AT29LV020	
	AT29C040	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	AT29C040A	
	AT29LV040A	
	AT49F010	
	AT49F001T	
	*AT49LV001	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*AT49BV001	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*AT49LV001T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*AT49BV001T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*AT49LV001N	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*AT49BV001N	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*AT49LV001NT	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*AT49BV001NT	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	AT49F020	
	AT49LV020	
	AT49F002T	
	*AT49F002N	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*AT49F002NT	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	AT49F040	
	*AT49F4096	LP-PSOP-29F100
	AT49LV040(T)	
	AT49LV040(J)	
	AT49BV040(T)	
	AT49BV040(J)	
	AT49LV040T(T)	
	AT49LV040T(J)	
	AT49BV040T(T)	
	AT49BV040T(J)	
	AT49LV080(T)	
	AT49BV080(T)	
	AT49LV080T(T)	
	*AT49BV512	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	AT49BV080T(T)	
	AT49LV8192(T)	
	AT49LV8192T(T)	
	AT49BV8192(T)	
	AT49BV8192T(T)	
	AT59C11	
	AT59C13	
	AT87F51	
	AT89C51	
	AT89F51	
	AT89LV51	
	AT89C52	
	AT89F52	
	AT89LV52	
	AT89S53	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	AT89C55	
	AT89C55WD	
	AT89C1051	
	AT89C2051	
	AT89C4051	
	AT89S8252	
	AT89LS8252	
	AT90S1200	
	AT90S1200A	
	AT90S2313	
	AT90S4414	
	AT90S8515	
	AT93C46A	
	AT93C46	
	AT93C46(SO-J)	
	AT93C56	
	AT93C56(SO-J)	
	AT93C66	
	AT93C66(SO-J)	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<i>BRIGHT</i>	BM29F400T	
	BM29F400B	
	BM29F400BT	
	BM29F400BB	
	BM29F040	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
CATALYST	CAT22C10/I	
	CAT22C12/I	
	CAT24C02	
	CAT24C02A	
	CAT24C04	
	CAT24C08	
	CAT24C16	
	CAT24C16V3	
	CAT24C32	
	CAT24C64	
	CAT24LC02	
	CAT24LC02A	
	CAT24LC04	
	CAT24LC08	
	CAT24LC16	
	CAT24C44/I	
	CAT27C64A	
	CAT27128A	
	CAT27256	
	CAT27HC256	
	CAT27512	
	CAT27010	
	CAT27C210	
	CAT28C16A	
	CAT28C17A	
	CAT28C64A	
	CAT28C64B/BI	
	CAT28C65A	
	CAT28C65B/BI	
	CAT28C256	
	CAT28F512	
	CAT28F512V5	
	CAT28F010	
	CAT28F010V5	
	CAT28F001P-T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	CAT28F001P-B	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	CAT28F001T-T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	CAT28F001T-B	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	CAT28F020	
	CAT28F002P-T	
	CAT33C104	
	CAT33C108	
	CAT33C116	
	CAT35C104	
	CAT35C108	
	CAT35C116	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	CAT59C11	
	CAT93C46	
	CAT93C46A	
	CAT93C46B	
	CAT93C46P	
	CAT93C46AP	
	CAT93C46_SO-J	
	CAT93C56	
	CAT93LC56	
<u>CMOS40</u>	4001	
	4002	
	4009	
	4010	
	4011	
	4012	
	4013	
	4015	
	4016	
	4017	
	4018	
	4019	
	4020	
	4021	
	4022	
	4023	
	4024	
	4025	
	4026	
	4027	
	4028	
	4029	
	4030	
	4032	
	4035	
	4038	
	4040	
	4041	
	4042	
	4043	
	4044	
	4048	
	4049	
	4050	
	4051	
	4052	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	4053	
	4054	
	4056	
	4060	
	4063	
	4066	
	4068	
	4068(RCA)	
	4069	
	4070	
	4071	
	4072	
	4073	
	4075	
	4076	
	4077	
	4078	
	4081	
	4082	
	4085	
	4086	
	4093	
	4095	
	4096	
	4099	
	40101	
	40104	
	40106	
	40107	
	40147	
	40160	
	40162	
	40161	
	40163	
	40174	
	40182	
	40192	
	40257	
<u>CMOS45</u>	4501	
	4502	
	4503	
	4510	
	4511	
	4512	
	4513	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	4514	
	4515	
	4516	
	4518	
	4519	
	4520	
	4522	
	4526	
	4529	
	4532	
	4539	
	4543	
	4555	
	4556	
	4560	
	4561	
	4572	
	4581	
	4582	
	4583	
	4584	
	4585	
<u>CYPRESS</u>	PALC16L8	
	PALC16R4	
	PALC16R6	
	PALC16R8	
	PALCE16V8	
	PALCE20V8	
	PALC22V10	
	PALC22V10D	
	CY27C256	
	CY27H256	
	CY27H512	
	CY27C010	
	CY27H010	
	CY7C185	
	CY7C245	
	CY7C245A	
	CY7C251	
	CY7C254	
	CY7C281	
	CY7C282	
	CY7C291	
	CY7C291A	
	CY7C292	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	CY7C292A	
	CY7C293A	
	*CY7C371	LP-PLCC-7C371

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>DALLAS</u>	DS1220AB	
	DS1220AD	
	DS1220Y	
	DS1225AB	
	DS1225AD	
	DS1225D	
	DS1225E	
	DS1225Y	
	DS1230AB	
	DS1230Y	
	DS1235AB	
	DS1235Y	
	DS1643	
	DS87C520	
	DS5000-32-8	
	DS5000-32-12	
	DS5000-32-16	
	DS5000-8-8	
	DS5000-8-12	
	DS5000-8-16	
	DS5000T-32-8	
	DS5000T-32-12	
	DS5000T-32-16	
	DS5000T-8-8	
	DS5000T-8-12	
	DS5000T-8-16	
<u>DRIVER</u>	75450	
	75451	
	75452	
	75453	
	75461	
	75462	
	75463	
	75471	
	75472	
	75473	
	2003	
	2004	
	P8216	
	P8226	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>EA</u>	2716	
<u>EDI</u>	EDI8810	
	EDI8832	
	EDI88128	
<u>EMC</u>	EM78P156	
	EM78P154	
	EMC78P447SB	
<u>EON</u>	*EN29F002T/B/NT/NB	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
<u>EUROTECHNIQUE</u>	ET2716	
	ET2732	
<u>EXEL</u>	XL24C01A	
	XL24C02	
	XL24C04	
	XL24C04-3	
	XL24C16	
	XL2816	
	XL2816A	
	XL28C16A	
	XL28C16B	
	XL2817A	
	XL2864A	
	XL28C64	
	XL28C64B	
	XL28F010	
	XL28F020	
	XL46C15	
	XL9020	
	XL90C21	
	XL9040	
	XL93LC06A	
	XL93C46	
	XL93CS46	
	XL93CS46-3	
	XL93LC46	
	XL93LC46A	
	XL93LL46	
	XL93C46_SO-F	
	XL93LC46_SO-F	
	XL93CS46_SO-F	
	XL93LC56	
	XL93LC56A	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	XL93LL56	
	XL93LC56_SO-F	
	XL93LL56_SO-F	
	XL93C66	
	XL93LC66	
	XL93LC66A	
	XL93LL66	
	XL93LC66_SO-F	
	XL93LL66_SO-F	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
Fujitsu	MBM2212	
	MBM2716	
	MB8516	
	MBM2732	
	MBM2732A	
	MBM27C32A	
	MBM2764	
	MBM27C64	
	MBM27128	
	MBM27128A	
	MBM27C128	
	MBM27256	
	MBM27C256	
	MBM27C256A/H	
	MBM27512	
	MBM27C512	
	MBM27C1000	
	MBM27C1001	
	MBM27C1001A	
	MBM27C2001	
	MBM27C4001	
	MBM27C1024	
	MBM27C1024A	
	MBM27C2048	
	MBM27C4096	
	MBM28F010	
	MBM29F002B	
	MBM29F002T	
	*MBM29F200BA	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	MBM29F040A	
	*MBM29F400BC	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29F400TA	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29F080	LP-TSOP-2XF008
	*MBM29F800T	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	MBM29F800BA	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29F016	LP-TSOP-29F016
	*MBM29LV200B	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29LV200T	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29LV200TA	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29LV400B	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29LV400T	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29LV800B	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29LV800T	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*MBM29F800BA(TSOP)	LP-TSOP-48-2XFX00
	*MBM29LV160T(TSOP)	LP-TSOP-48-2XFX00A
	*MBM29LV160B(TSOP)	LP-TSOP-48-2XFX00A

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	MB811000	
	MB81464	
	MB81256	
	MB814256	
	MB814400	
	MB8264	
	MB8428	
	MB8464A	
	MB84256	
	8749H	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>GeneralType</u>	4164	
	4464	
	41256	
	44256	
	41000	
	44400	
	411000	
	414000	
	6116	
	6264	
	62256	
	628128	
	IS61C512	
	628512	
<u>GENERAL</u>	HD46821	
	HD6321	
	6821	
	68SC21	
	uPD71055	
	CXQ71055	
	CXQ71059	
	uPD71059C	
	8155H	
	81C55A	
	8156H	
	8243	
	8255	
	8255A	
	82C55A	
	8259A	
	82C59A	
	MB8874	
	MB89255A	
	MB89259	
<u>GI</u>	GR2764	
	GR27128	
	GR27256	
	GR27512	
	GR27513	
<u>Goldstar</u>	GM76C8128	
<u>GOULD</u>	PEEL18CV8	
	20CG10	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
HITACHI	BR9020	
	HN62428P	
	HN624116P	
	HN27C64G	
	HN27128AG	
	HN27128AP	
	HN27C128	
	HN27256G	
	HN27256P	
	HN27C256G	
	HN27512G	
	HN27C512AG	
	HN27C101G/AG	
	HN27C301G/AG	
	HN27C4001G	
	HN27C4000G	
	HN27C1024G	
	HN27C4096G	
	HN27C4096AG	DIP
	HN28F101P	
	*HD4074314	LP-SDIP-HD4074314/16/18
	*HD4074316	LP-SDIP-HD4074314/16/18
	*HD4074318	LP-SDIP-HD4074314/16/18
	*HD407L4818H	LP-PQFP-80PIN
	HN462716	
	HN462732	
	HN462732P	
	HN462732A	
	HN462732G	
	HN482732A	
	HM4864	
	HN482764	
	HN4827128	
	HN4827128P	
	HM50464	
	HM50256	
	HM511000	
	HM514400	
	HM514100	
	HN58C64P	
	HN58C65P	
	HN58C256	
	HM6116	
	HM6116L	
	HM6116A	
	HM6116AL	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	HM6264	
	HM6264A	
	HM6264L	
	HM6264AL	
	HM6264FP	
	HM62256	
	HM62256L	
	HM62256FP	
	HM628128P	
	HM628128LP	
	HM628128FP	
	HM628128LFP	
	HM628512LFP	
	*HD647180	LP-PLCC-HD647180
	*HD64F3048F	LP-QFP-HD64F3048F
	*HD64F3434TF	LP-TQFP-HD64F3434TF
	*HD64F3437TF	LP-TQFP-HD64F3434TF
	HD6473644TF	
	*HD6473337TF	LP-PLCC-HD6473337
<u>HOLTEK</u>	HT24C01	
	HT24C02	
	HT24C04	
	HT24C08	
	HT24C16	
	HT27C256	
	HT27PC256	
	HT27PC512	
	HT27PC010	
	HT48R11-20DIP'	
	HT48R11-16DIP'	
	HT48R12-16DIP'	
	HT48R31-18DIP'	
	HT48R31-20DIP'	
	HT48R31-24DIP'	
	HT48R31-28DIP'	
	HT48R50-28DIP'	
	HT6P20	
	HT6P20A	
	HT6P20B	
	HT6P20C	
	HT6P20D	
	HT6P20E	
	HT93C46	
	HT93LC46	
	HT93C46-SOPA	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	HT93LC46-SOPA	
	HT93C46-SOPB	
	HT93LC46-SOPB	
<u>HYUNDAI</u>	HY18CV8	
	HY27C64	
	HY27C64A	
	HY93C46	
	HY51C64	
	HY53C464	
	HY53C256	
	HY51C4256	
	HY51C1000	
	HY6116	
	HY61C16	
	HY61C16A	
	HY6264	
	HY62C64	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>ICT</u>	27CX256	
	27CX010	
	93C46	
	93C46A	
	93CX46	
	93C46(SO8)	
	93C46A(SO8-S)	
	93C56	
	93CX56	
	93C66	
	93CX66	
	PEEL18CV8	
	PEEL22CV8	
	PEEL20CG10	
	PEEL22CV10	
	PEEL22CV10A	
	PEEL22CV10A+	
	PEEL22CV10AZ+	
	PA7024	
	PA7128	
	PA7140	
<u>IDT</u>	IDT6116	
	IDT7164	
	IDT71256	
	78C16A	
<u>IMT</u>		
	IM29F002T	
<u>intel</u>	2128	
	P21464	
	B2716	
	D2716	
	D2732	
	D2732A	
	D2732B	
	P2732A	
	D2764	
	D2764A	
	D27C64	
	P2764	
	P2764A	
	D27128	
	D27128A	
	D27128B	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	P27128A	
	D27256	
	D27C256	
	P27256	
	27512	
	27C512	
	P27512	
	27513	
	27C513	
	27C010	
	27C010A	
	27C011	
	27C020	
	27C040	
	27C080	
	27C210	
	27C220	
	27C240	
	27C400	
	82802AA	
	82802AB	
	82802AC	
	i2816	
	i2816A	
	i2817A	
	i2864A	
	N28F256	
	N28F256A	
	N28F512	
	N28F010	
	N28F020	
	E28F004B5-T	
	E28F004B5-B	
	*E28F200B5-T	LP-TSOP-2XFX00
	*E28F200B5-B	LP-TSOP-2XFX00
	*E28F400B5-T	LP-TSOP-2XFX00
	*E28F400B5-B	LP-TSOP-2XFX00
	*E28F800B5-T	LP-TSOP-2XFX00
	*E28F800B5-B	LP-TSOP-2XFX00
	*PA28F200B5-T	LP-PSOP-PA28F400
	*PA28F200B5-B	LP-PSOP-PA28F400
	*TB28F200B5-T	LP-PSOP-28F400
	*TB28F200B5-B	LP-PSOP-28F400
	*PA28F400B5-B	LP-PSOP-PA28F400
	*PA28F400B5-T	LP-PSOP-PA28F400
	*TB28F400B5-T	LP-PSOP-28F400

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	*TB28F400B5-B	LP-PSOP-28F400
	*PA28F800B5-T	LP-PSOP-PA28F400
	*PA28F800B5-B	LP-PSOP-PA28F400
	*TB28F800B5-T	LP-PSOP-28F400
	*TB28F800B5-B	LP-PSOP-28F400
	E28F002BC-T	
	PA28F002BC-T	
	TE28F004BE-T	
	TE28F004BE-B	
	TE28F008BE-T	
	TE28F008BE-B	
	E28F002BL-T	
	E28F002BL-B	
	*PA28F200BL-T	LP-PSOP-28F400
	*PA28F200BL-B	LP-PSOP-28F400
	E28F002BV-T	
	E28F002BV-B	
	*E28F004BV-T	LP-TSOP-2XF008
	*E28F004BV-B	LP-TSOP-2XF008
	*E28F008BV-T	LP-TSOP-2XF008
	*E28F008BV-B	LP-TSOP-2XF008
	*PA28F200BV-T	LP-PSOP-PA28F400
	*PA28F200BV-B	LP-PSOP-PA28F400
	*PA28F400BV-T	LP-PSOP-PA28F400
	*PA28F400BV-B	LP-PSOP-PA28F400
	*PA28F800BV-T	LP-PSOP-PA28F400
	*PA28F800BV-B	LP-PSOP-PA28F400
	*TB28F200BV-B	LP-PSOP-28F400
	*TB28F200BV-T	LP-PSOP-28F400
	*TB28F400BV-T	LP-PSOP-28F400
	*TB28F400BV-B	LP-PSOP-28F400
	*TB28F800BV-B	LP-PSOP-28F400
	*TB28F800BV-T	LP-PSOP-28F400
	*E28F001BX-B	LP-TSOP-32PIN
	*E28F001BX-T	LP-TSOP-32PIN
	P28F001BX-T	DIP
	P28F001BX-B	DIP
	E28F002BX-T	
	E28F002BX-B	
	*PA28F200BX-T	LP-PSOP-28F400
	*PA28F200BX-B	LP-PSOP-28F400
	*PA28F400BX-B	LP-PSOP-PA28F400
	*PA28F400BX-T	LP-PSOP-PA28F400
	*PA28F800BX-B	LP-PSOP-PA28F400
	*PA28F800BX-T	LP-PSOP-PA28F400
	*TB28F200BX-T	LP-PSOP-PA28F400

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	*TB28F200BX-B	LP-PSOP-PA28F400
	*TE28F400CE-T	LP-TSOP-2XFX00
	*TE28F400CE-B	LP-TSOP-2XFX00
	*TE28F800CE-T	LP-TSOP-2XFX00
	*TE28F800CE-B	LP-TSOP-2XFX00
	*E28F200CV-T	LP-TSOP-2XFX00
	*E28F200CV-B	LP-TSOP-2XFX00
	*E28F400CV-T	LP-TSOP-2XFX00
	*E28F400CV-B	LP-TSOP-2XFX00
	E28F800CV-B	
	E28F800CV-T	
	*E28F320J5	LP-TSOP-56-28F320
	E28F004S3	
	E28F008S3	
	E28F016S3	
	*PA28F004S3	LP-PSOP-28F400A
	*PA28F008S3	LP-PSOP-28F400A
	*PA28F016S3	LP-PSOP-28F400A
	*TB28F004S3	LP-PSOP-28F400A
	*TB28F008S3	LP-PSOP-28F400A
	*TB28F016S3	LP-PSOP-28F400A
	E28F004S5	
	*E28F008S5	LP-TSOP-2XF008
	E28F016S5	
	TE28F004S5	
	TE28F008S5	
	TE28F016S5	
	*PA28F004S5	LP-PSOP-28F400A
	*PA28F008S5	LP-PSOP-28F400A
	*PA28F016S5	LP-PSOP-28F400A
	*TB28F004S5	LP-PSOP-28F400A
	*TB28F008S5	LP-PSOP-28F400A
	*TB28F016S5	LP-PSOP-28F400A
	*E28F008SA	LP-TSOP-2XF008
	*E28F008SA-L	LP-TSOP-2XF008
	PA28F008SA-L	
	E28F004SC	
	E28F008SC	
	E28F016SC	
	*PA28F004SC	LP-PSOP-28F400A
	*PA28F008SC	LP-PSOP-28F400A
	*PA28F016SC	LP-PSOP-28F400A
	*TB28F004SC	LP-PSOP-28F400A
	*TB28F008SC	LP-PSOP-28F400A
	*TB28F016SC	LP-PSOP-28F400A
	P51256	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	D8741	
	D8741A	
	D8741AH	
	P8741AH	
	8744H	
	D8748	
	D8748H	
	D8748AH	
	D8749	
	D8749H	
	D8749AH	
	D8750	
	D8750H	
	D8750AH	
	87C51	
	8751H	
	8751BH	
	87C51FA	
	87C51FB	
	87C51FC	
	*87C51GB	LP-PLCC-87C51GB
	8752	
	8752H	
	8752BH	
	87C52	
	87C54	
	87L54	
	D8755A	
	D8755AD	
	87C64	
	*87C196KB	LP-PLCC-87C196
	*87C196KC	LP-PLCC-87C196
	*87C196KD	LP-PLCC-87C196
	*87C196MC	LP-PLCC-87C196MC
	*87C196MD	LP-PLCC-87C196MC
	*87C196MH	LP-PLCC-87C196MC
	*87C251SB(A)	LP-PLCC-87C251SB
	*87C251SB(B)	LP-PLCC-87C251SB
	87C252	
	87C256	
<u>ISSI</u>		
	IS89C51	
	IS89C52	
	IS24C02	
	IS24C02-3	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	IS24C04	
	IS24C04-3	
	IS27C256	
	IS27HC256	
	IS27C512	
	IS27HC512	
	IS27LV512	
	IS27C010	
	IS27HC010	
	IS27LV010	
	IS28F010	
	IS28F020	
	IS61C64	
	IS61C64A	
	IS61C256	
	IS61C512	
	IS61C1024	
	IS93C46	
	IS93C46_SOG	
	IS93C46-3	
	IS93C56-3	
	IS93C56-3_SOG	
	IS93C66	
	IS93C66-3	
	IS93C66_SOG	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>Lattice</u>	GAL16V8/A/B	
	GAL16V8C/D	
	GAL16V8B-7	
	GAL16V8C-5	
	GAL16V8Z	
	GAL20V8/A/B	
	GAL20V8B-7	
	GAL20V8C-5	
	GAL22V10/B	
	GAL22V10C-5	
	GAL6001	
	*ispLSI1016	LP-PLCC-PLSI1016
	*ispLSI1024	LP-PLCC-PLSI1024
	*ispLSI1032	LP-PLCC-PLSI1032
	*ispLSI1048	LP-PQFP-PLSI1048
	*ispLSI1048C	LP-PQFP-PLSI1048C
	*ispLSI2032	LP-PLCC-PLSI1016
	*ispLSI2064	LP-PLCC-PLSI1032
<u>LG</u>	GMS97C51	
	GMS97C52	
	GMS97C54	
	GMS97C56	
	GMS97C58	
	*GMS97C1051	LP-DIP-LG97C2051
	*GMS97C2051	LP-DIP-LG97C2051
	GMS80C701	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>MATSHUSHITA</u>	MN2716	
	MN2732	
	MN2764	
	MN27C64	
	MN27HC64	
	MN27128	
<u>MHS</u>	HM65161	
	HM65162	
	HM65764	
	HM20256	
<u>MICON</u>	MDT2005	
	MDT2010	
<u>Microchip</u>	24C01A	
	24C02A	
	24C04A	
	24C08B	
	24C16B	
	24C32	
	24C65	
	24AA01	
	24AA02	
	24AA04	
	24AA08	
	24AA16	
	24AA65	
	24AA164	
	24AA174	
	24LC01B	
	24LC02B	
	24LC04B	
	24LC08B	
	24LC16B	
	24LC21	
	24LC32	
	24LC41A	
	24LC64	
	24LC65	
	24LC128	
	24LC164	
	24LC174	
	24LC256	
	24LCS52	
	2764	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	27C64	
	27LV64	
	27HC64	
	27C128	
	27256	
	27C256	
	27HC256	
	27LV256	
	27C512	
	27C512A	
	27HC512	
	27LV512	
	28C04A	
	28C16A	
	2817A	
	28C64A	
	37LV36	
	37LV65	
	37LV128	
	59C11	
	85C82	
	93C06	
	93C46	
	93C46X	
	93C56	
	93C66	
	93C76	
	93C86	
	93AA46	
	93AA46X	
	93AA56	
	93AA56X	
	93AA66	
	93AA66X	
	93AA76	
	93AA86	
	93LC46	
	93LC46A	
	93LC46B	
	93LC46BX	
	93LC46X	
	93LC56	
	93LC56X	
	93LC66	
	93LC66X	
	93LC56B	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	93LC56BX	
	93LC66B	
	93LC66BX	
	93LC76	
	93LC86	
	93LCS56	
	93LCS66	
	HCS200	
	HCS300	
	HCS301	
	HCS509	
	HCS512	
	PIC12C508	DIP,LP-SOP-8PIN-B
	PIC12C508(98)	DIP,LP-SOP-8PIN-B
	PIC12C508A	DIP,LP-SOP-8PIN-B
	PIC12C509	DIP,LP-SOP-8PIN-B
	PIC12C509A	DIP,LP-SOP-8PIN-B,LP-SOP-16PIN
	PIC12C509(98)	DIP,LP-SOP-8PIN-B
	PIC12CE519	DIP,LP-SOP-8PIN-B,LP-SOP-16PIN
	PIC12CE519(98)	DIP,LP-SOP-8PIN-B,LP-SOP-16PIN
	PIC12C671	DIP,LP-SOP-8PIN-B
	PIC12C672	DIP,LP-SOP-8PIN-B
	*PIC14C000	LP-DIP-PIC14000
	PIC16C505	DIP-LP-SOP-16PIN
	PIC16C52	DIP,LP-SOP-28B
	PIC16C52(98)	DIP,LP-SOP-28B
	PIC16C52-XT	DIP,LP-SOP-28B
	PIC16C52-RC	DIP,LP-SOP-28B
	PIC16C54	DIP,LP-SOP-28B
	PIC16C54(98)	DIP,LP-SOP-28B
	PIC16C54A	DIP,LP-SOP-28B
	PIC16C54A(98)	DIP,LP-SOP-28B
	PIC16C54B	DIP,LP-SOP-28B
	PIC16C54B(98)	DIP,LP-SOP-28B
	PIC16C54-LP	DIP,LP-SOP-28B
	PIC16C54-XT	DIP,LP-SOP-28B
	PIC16C54-HS	DIP,LP-SOP-28B
	PIC16C54-RC	DIP,LP-SOP-28B
	PIC16C54C	DIP,LP-SOP-28B
	PIC16C55	DIP,LP-SOP-28B
	PIC16C55(98)	DIP,LP-SOP-28B
	PIC16C55-LP	DIP,LP-SOP-28B
	PIC16C55-XT	DIP,LP-SOP-28B
	PIC16C55-HS	DIP,LP-SOP-28B
	PIC16C55-RC	DIP,LP-SOP-28B
	PIC16C554	DIP,LP-SOP-28B

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	PIC16C558	DIP,LP-SOP-28B
	PIC16C56	DIP,LP-SOP-28B
	PIC16C56(98)	DIP,LP-SOP-28B
	PIC16C56-LP	DIP,LP-SOP-28B
	PIC16C56-XT	DIP,LP-SOP-28B
	PIC16C56-HS	DIP,LP-SOP-28B
	PIC16C56-RC	DIP,LP-SOP-28B
	PIC16C57	DIP,LP-SOP-28B
	PIC16C57C	DIP,LP-SOP-28B
	PIC16C57(98)	DIP,LP-SOP-28B
	PIC16C57-LP	DIP,LP-SOP-28B
	PIC16C57-XT	DIP,LP-SOP-28B
	PIC16C57-HS	DIP,LP-SOP-28B
	PIC16C57-RC	DIP,LP-SOP-28B
	PIC16C58A	DIP,LP-SOP-28B
	PIC16C58A(98)	DIP,LP-SOP-28B
	PIC16C58B	DIP,LP-SOP-28B
	PIC16C58B(98)	DIP,LP-SOP-28B
	*PIC16C61	LP-DIP-PIC16A
	PIC16C62	DIP,LP-SOP-28B
	PIC16C62A	DIP,LP-SOP-28B
	PIC16C63	DIP,LP-SOP-28B
	PIC16C63A	DIP,LP-SOP-28B
	*PIC16C64	LP-DIP-PIC16A
	*PIC16C64A	LP-DIP-PIC16A
	*PIC16C65	LP-DIP-PIC16A
	*PIC16C65A	LP-DIP-PIC16A
	PIC16C66	DIP,LP-SOP-28B
	*PIC16C67	LP-DIP-PIC16A
	*PIC16C71	LP-DIP-PIC16A
	PIC16C711	LP-DIP-PIC16A
	PIC16C715	
	PIC16C72	DIP,LP-SOP-28B
	PIC16C72A	DIP,LP-SOP-28B
	PIC16C73	DIP,LP-SOP-28B
	PIC16C73A	DIP,LP-SOP-28B
	PIC16C73B	DIP,LP-SOP-28B
	*PIC16C74	LP-DIP-PIC16A
	*PIC16C74A	LP-DIP-PIC16A
	*PIC16C74B	LP-DIP-PIC16A
	PIC16C76	DIP,LP-SOP-28B
	*PIC16C84	LP-DIP-PIC16A
	*PIC16LC84	LP-DIP-PIC16A
	*PIC16C923	LP-PLCC-PIC16923
	*PIC16C924	LP-PLCC-PIC16923
	PIC16F83	DIP,LP-SOP-28B

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	PIC16F84	DIP,LP-SOP-28B
	PIC16LF84	DIP,LP-SOP-28B
	PIC16F877	LP-DIP-PIC16A, LP-PLCC-44- PIC16C64/65/74/A, LP-QFP-44- PIC16C64/65/74/A
	PIC16C620	DIP,LP-SOP-28B
	*PIC16C621	LP-DIP-PIC16A
	*PIC16C622	LP-DIP-PIC16A
	PIC17C42	DIP,LP-PLCC-MPU51
	PIC17C42A	DIP,LP-PLCC-MPU51
	PIC17C43	DIP,LP-PLCC-MPU51
	PIC17C44	DIP,LP-PLCC-MPU51
<u>MICRON</u>	MT4C4001	
	MT28F400B1T	
	MT28F400B1B	
<u>mitsubishi</u>	8748	
	M5L2716	
	M5L2732	
	M5L2732A	
	M5L2764	
	M5L27128	
	M5L27C128	
	M5L27256	
	M5L27C256	
	M5L27512	
	M5L27C512A	
	M5L27C100K	
	M5L27C101K	
	M5L27C201K	
	M5L27C401K	
	M5L27C1024K	
	M5L27C202K	
	M5M27C101K	
	M5M27C202K	
	M5M27C401AK	
	M5M27C402K	
	M5M28C64AP	
	M5M28F101	
	M6M80011	
	M6M80022	
	M5M5165	
	M5M5165P	
	M5M5165FP	
	M5M52256	
	M5M52256P	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	M5M52256AP	
	M5M52256FP	
	M5M51008FP	
	M5M51008P	
	M5M51008VP	
	M5M51008RV	
	M5M4164	
	M5M4464	
	M5M42256	
	M5M44256	
	M5M41000	
<u>MMI</u>	PAL10H8	
	PAL12H6	
	PAL14H4	
	PAL16H2	
	PAL16C1	
	PAL10L8	
	PAL12L6	
	PAL14L4	
	PAL16L2	
	PAL16L8	
	PAL16R4	
	PAL16R6	
	PAL16R8	
	PAL16X4	
	PAL16A4	
	PAL10H8-2	
	PAL12H6-2	
	PAL14H4-2	
	PAL16H2-2	
	PAL16C1-2	
	PAL10L8-2	
	PAL12L6-2	
	PAL14L4-2	
	PAL16L2-2	
	PAL16L8-2	
	PAL16R4-2	
	PAL16R6-2	
	PAL16R8-2	
	PAL16L8A	
	PAL16R4A	
	PAL16R6A	
	PAL16R8A	
	PAL16L8A-2	
	PAL16R4A-2	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	PAL16R6A-2	
	PAL16R8A-2	
	PAL16L8A-4	
	PAL16R4A-4	
	PAL16R6A-4	
	PAL16R8A-4	
	PAL16L8B	
	PAL16R4B	
	PAL16R6B	
	PAL16R8B	
	PAL16L8	
	PAL16R4	
	PAL16R6	
	PAL16R8	
	PAL16L8B	
	PAL16R4B	
	PAL16R6B	
	PAL16R8B	
	PAL16L8B-2	
	PAL16R4B-2	
	PAL16R6B-2	
	PAL16R8B-2	
	PAL16L8B-4	
	PAL16R4B-4	
	PAL16R6B-4	
	PAL16R8B-4	
	PAL16L8D	
	PAL16R4D	
	PAL16R6D	
	PAL16R8D	
	PAL16L8-10	
	PAL16R4-10	
	PAL16R6-10	
	PAL16R8-10	
	PALC16L8	
	PALC16R4	
	PALC16R6	
	PALC16R8	
	PAL12L10	
	PAL14L8	
	PAL16L6	
	PAL18L4	
	PAL20C1	
	PAL20L2	
	PAL20L8	
	PAL20L10	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	PAL20R4	
	PAL20R6	
	PAL20R8	
	PAL20X4	
	PAL20X8	
	PAL20X10	
	PAL20L8A	
	PAL20R4A	
	PAL20R6A	
	PAL20R8A	
	PAL20X4A	
	PAL20X8A	
	PAL20X10A	
	PAL20L8A-2	
	PAL20R4A-2	
	PAL20R6A-2	
	PAL20R8A-2	
	PAL20L8B	
	PAL20R4B	
	PAL20R6B	
	PAL20R8B	
	PAL20L8B-2	
	PAL20R4B-2	
	PAL20R6B-2	
	PAL20R8B-2	
	PAL20L8D	
	PAL20R4D	
	PAL20R6D	
	PAL20R8D	
	PALC22V10	
	63S080	
	63S081	
	63S140	
	63S141	
	63S240	
	63S241	
	63S280	
	63S281	
	63S440	
	63S441	
	63S480	
	63S481	
	63S840	
	63S841	
	63S880	
	63S881	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	63S1640	
	63S1641	
	63S1681	
	63S3281	
<u>MOSAIC</u>	MSM832	
	MSM8128	
<u>MOSEL-VITELIC</u>	V29C51001B	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	V29C51001T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	V29LC51001	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	V29C51002B	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	V29C51002T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	V29LC51002	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*V53C16256H	LP-SOJ-40PIN
<u>MOSTEK</u>	MK2716	
	MK2764	
	MK4802	
	MK48C02	
	MK48Z02	
	MK48Z08	
<u>MOTOROLA</u>	MCM2716	
	MCM4016	
	MCM6664	
	MCM6644	
	MCM6256	
	MCM5L1000	
	MCM5L4400	
	MCM5L4100	
	*MC68705R3	LP-DIP-68705
	*MC68705R5	LP-DIP-68705
	*MC68705P3	LP-DIP-68705
	*MC68705P5	LP-DIP-68705
	*MC68705U3	LP-DIP-68705
	*MC68705U5	LP-DIP-68705
	*MC68HC705C4	LP-DIP-68HC705CX
	*MC68HC705C4	LP-PLCC-68HC705CX
	*MC68HC705C4A	LP-DIP-68HC705CX
	*MC68HC705C4A	LP-PLCC-68HC705CX
	*MC68HC705C8	LP-DIP-68HC705CX
	*MC68HC705C8	LP-PLCC-68HC705CX
	*MC68HC705C8A	LP-DIP-68HC705CX
	*MC68HC705C8A	LP-PLCC-68HC705CX
	*MC68HC705P6	LP-DIP-68HC705P6A

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	*MC68HC705P6	LP-SOP-68HC705P6A
	*MC68HC705P6A	LP-DIP-68HC705P6A
	*MC68HC705P6A	LP-SOP-68HC705P6A
	*MC68HC705P9	LP-DIP-68HC705P6A
	*MC68HC705P9	LP-SOP-68HC705P6A
	*MC68HC705J2	LP-DIP-68HC705J2
	*MC68HC705J2	LP-SOP-MC68HC705J2
	*MC68HC711E9	LP-PLCC-68HC711E9
<u>MXIC</u>	MX10FLCDPC	DIP
	MX10F201FC	
	MX23C4096	
	MX23C8100	
	MX23C1610	
	MX23C3210	
	*MX25L4004	LP-TSOP-MX25L4004
	MX26C512A	
	MX26C1000A	
	MX27C256	
	MX27L256	
	MX27C512	
	MX27L512	
	MX27C1000	
	MX27L1000	
	MX27C1001	
	MX27C1024	
	MX27C2000	
	MX27L2000	
	MX27C2100	
	MX27C2048	
	MX27C4000	
	MX27L4000	
	MX27C4096	
	MX27C4100	
	MX27C4111	
	MX27C8000	
	MX27C8100	
	MX28F002T	
	MX28F002B	
	MX28F1000	
	MX28F2000P	
	MX28F2000T	
	*MX28F2100B	LP-TSOP-MX29F1610/F8100
	MX28F4000	
	*MX29F8100	LP-TSOP-MX29F1610/F8100
	*MX29F8100	LP-PSOP-PA28F400

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	*MX29F1610	LP-TSOP-MX29F1610/F8100
	*MX29F1610	LP-PSOP-PA28F400
	MX29F001T	
	MX29F001B	
	MX29F002T	
	MX29F002B	
	MX29F002NT	
	MX29F002NB	
	MX29F004T	
	MX29F004B	
	*MX29F040	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*MX29F200TTC	LP-TSOP-48-2XFX00
	*MX29F200BTC	LP-TSOP-48-2XFX00
	*MX29F400TTC	LP-TSOP-48-2XFX00
	*MX29F400BTC	LP-TSOP-48-2XFX00
	*MX29F400TMC	LP-PSOP-28F400
	*MX29F400BMC	LP-PSOP-28F400
<u>MYSON</u>	MTM356	
	MTV112M	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
NEC	*uPD17P149	LP-SOP-uPD17P149
	*uPD17P149	LP-SDIP-uPD17P149
	uPD2716	
	uPD2732	
	uPD2732A	
	uPD2732B	
	uPD2764	
	uPD2764D	
	uPD27C64C	
	uPD27C64D	
	uPD27128	
	uPD27128C	
	uPD27128D	
	uPD27C128D	
	uPD27256	
	uPD27256D	
	uPD27256A/AD	
	uPD27C256A/AD	
	uPD27C256D	
	uPD27512A	
	uPD27512AC	
	uPD27512AD	
	uPD27C512D	
	uPD271000D	
	uPD27C1000	
	uPD271001	
	uPD27C1001	
	uPD27C1024	
	uPD27C1024A	
	uPD27C2001	
	uPD27C4000D	
	uPD27C4001	
	uPD27C4096	
	uPD27C8000	
	uPD27C8001	
	*uPD75P108B	LP-SDIP-uPD75P108B
	*uPD75P108B	LP-QFP-uPD75P108B
	*uPD75P3018GC	LP-QFP-uPD75P3018
	*uPD75P3018GK	LP-TQFP-uPD75P3018
	*uPD75P308	LP-QFP-uPD75P3XXB
	*uPD75P316GF	LP-QFP-uPD75P3XXB
	*uPD78P048A	LP-QFP-PA78P048GF
	*uPD78P054GK	LP-TQFP-uPD78P054
	*uPD78P054GC	LP-QFP-uPD78P054
	uPD8741A	
	uPD8748	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	uPD8748H	
	uPD8749H	
	uPD8755A	
	uPD4164	
	uPD41464	
	uPD41256	
	uPD421000	
	uPD424400	
	uPD424100	
	uPD43256	
	uPD431000	
<u>NS</u>	GAL16V8-20	
	GAL16V8-25	
	GAL16V8-35	
	GAL16V8A-10	
	GAL16V8A-12	
	GAL16V8A-15	
	GAL16V8A-20	
	GAL20V8-20	
	GAL20V8-25	
	GAL20V8-35	
	GAL20V8A-10	
	GAL20V8A-12	
	GAL20V8A-15	
	GAL20V8A-20	
	GAL22V10-15	
	GAL22V10-25	
	GAL6001	
	PAL10L8	
	PAL10L8A	
	PAL10H8A	
	PAL12H6A	
	PAL12L6	
	PAL12L6A	
	PAL14H4A	
	PAL14L4	
	PAL14L4A	
	PAL16C1	
	PAL16C1A	
	PAL16H2	
	PAL16H2A	
	PAL16L2	
	PAL16L2A	
	PAL16L8	
	PAL16L8A	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	PAL16L8B	
	PAL16R4	
	PAL16R4A	
	PAL16R4B	
	PAL16R6	
	PAL16R6A	
	PAL16R6B	
	PAL16R8	
	PAL16R8A	
	PAL16R8B	
	PAL12L10	
	PAL14L8	
	PAL16L6	
	PAL18L4	
	PAL20C1	
	PAL20L2	
	PAL20X4	
	PAL20X4A	
	PAL20L8A	
	PAL20L8B	
	PAL20L10A	
	PAL20R4A	
	PAL20R4B	
	PAL20R6A	
	PAL20R6B	
	PAL20R8A	
	PAL20R8B	
	NM24C02	
	NM24C02L	
	NM24C03	
	NM24C03L	
	NM24C04	
	NM24C04L	
	NM24C05	
	NM24C05L	
	NM24C08	
	NM24C08L	
	NM24C09	
	NM24C09L	
	NM24C16	
	NM24C16L	
	NM24C17	
	NM24C17L	
	NM34C02	
	NMC2716	
	NMC27C16	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	NMC27C16B	
	NMC27C16H	
	NMC2732	
	NMC27C32	
	NMC27C32B	
	NMC27C32H	
	NMC2764	
	NMC2764H	
	NMC27C64	
	NMC27LC64	
	NMC27CP128	
	NMC27C128B	
	NMC27256	
	NMC27C256	
	NMC27C256B/C	
	NMC27LC256	
	NMC27C512	
	NMC27C512A	
	NMC27LC512	
	NMC27LV512	
	NMC27C010	
	NMC27LV010	
	NMC27C020	
	NMC27C040	
	NMC27P040	
	NMC27C1024	
	NMC27C2048	
	NMC9306	
	NMC93C06	
	NMC93CS06	
	NMC9307	
	NMC93C07	
	NMC9346	
	NMC9346E	
	NMC93C46	
	NMC93C46LZ	
	NMC93CS46	
	NMC93C56	
	NMC93CS56	
	NMC93CS56L	
	NMC93C66	
	NMC93C66L	
	NMC93C66LZ	
	NMC93CS66	
	NMC93CS66L	
	NM93C86	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	54S287	
	74S188	
	74S287	
	74S288	
	74S387	
	74S471	
	74S472	
	74S473	
	74S570	
	74S571	
	74S572	
	74S573	
	87S180	
	87S181	
	87S184	
	87S185	
	87S190	
	74S191	
	87S195	
	87S280	
	87S281	
	87S290	
	87S291	
	87S321	
	87S421	
	9816A	
	9817A	
	98C64	
	*COP8780C	LP-DIP-COP8780
	*COP8781C	LP-DIP-COP8780
	*COP8782C	LP-DIP-COP8780

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>OKI</u>	MSM2716	
	MSM2732	
	MSM2732A	
	MSM2764	
	MSM2764A	
	MSM2764Z	
	MSM27C64	
	MSM27128	
	MSM27128A	
	MSM27C128	
	MSM27256	
	MSM27C256Z	
	MSM27C256H	
	MSM27512	
	MSM27512Z	
	MSM27512ZB	
	MSM271000	
	MSM27C2000	
	MSM27C401	
	MSM27C1024	
	MSM27C2048	
	MSM2816A	
	MSM16811	
	MSM16811P	
	MSM16911	
	MSM16911P	
	M5165	
	M51257RS	
	M51257JS	
	M51257LR	
	M3764	
	M41464	
	M41256	
	M414256	
<u>OMNI-WAVE</u>	27C256	
	27C101	
	27C1024	
<u>OPTO</u>	PC817	
	PC827	
	PC837	
	PC847	
	PC-17T1	
	PC-17T2	
	PC-17T4	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>Panasonic</u>	MN2764	
	MN41C1000	
<u>PHILIPS</u>	87C51	
	87C51FA	
	87C51FB	
	87C51FC	
	87C52	
	87C528	
	87C54	
	87C58	
	87C652	
	87C654	
	*87C451	LP-PLCC-87C451
	*87C552	LP-PLCC-87C552
	*87C748	LP-DIP-87C751,LP-PLCC-87C751
	*87C749	LP-DIP-87C751,LP-PLCC-87C751
	*87C750	LP-DIP-87C751,LP-PLCC-87C751
	*87C751	LP-DIP-87C751,LP-PLCC-87C751
	*87C751(PLCC)	LP-DIP-87C751,LP-PLCC-87C751
	*87C752	LP-DIP-87C751,LP-PLCC-87C751
	P87LPC764	DIP Short textool 11,16
	*P89C52NBA	LP-PLCC-MPU51
	P89C52NBPN	DIP
	*P89C54NBA	LP-PLCC-MPU51
	P89C54NBPN	DIP
	P89C138	
	P89C238	
	P89C738ABP	
	PCF8582E	
	PCX8594X	
	*P51XAG37	LP-PLCC-P51XAG37
<u>Pioneer</u>	PDH001	
<u>PMC</u>	*PM29F002T	LP-PLCC-1M32,LP-TSOP-32PIN
	*PM29F002B	LP-PLCC-1M32,LP-TSOP-32PIN

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>RCA</u>	CDM6116	
	CDM6264	
<u>RICOH</u>	RD27C32	
	RD27C64	
	RD27C128	
	RD27C256	
<u>Rockwell</u>		
	2804A P87C64	
	2816A	
	2864A	
	28C256	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>Samsung</u>	CPL16L8	
	CPL16R4	
	CPL16R6	
	CPL16R8	
	CPL22V10	
	28C16A	
	28C17A	
	28C64A	
	28C65A	
	KM28C256	
	*KM29N040T	LP-TSOPII-TC5816AFT
	*KM29V040T	LP-TSOPII-TC5816AFT
	*KM29N16000TS	LP-TSOPII-TC5816AFT
	KM4164	
	KM41256	
	KM93C06	
	KM93C07	
	KM93C46	
	KM93C46V	
	KM93C56	
	KM93C56V	
	KM93CS56	
	KM93C57	
	KM93C57V	
	KM93C66	
	KM93C66V	
	KM93CS66	
	KM93C67	
	KM93C67V	
<u>SANYO</u>	CL3518	
	CL3664	
	CL36256	
<u>SeeQ</u>	2764	
	27128	
	27256	
	27C256	
	2804A	
	2816A	
	2816AH	
	2817A	
	2864A	
	28C256	
	52B13	
	52B13H	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	5516	
	5517A	
	5517AH	
<u>Seiko</u>	SPM27C64H	
	SPM27128H	
	SPM27C256H	
	S2817A	
	S2864A	
	S28F512A	
	S-2100R	
	S-22H10R/I	
	S-22S10R/I	
	S-22H12R/I	
	S-22S12R/I	
	S-24H45R/I	
	S-24S45R/I	
	S-24S45(SOP)	
	S-24H45(SOP)	
	S-2913A	
	S-2913A(SOP)	
	S-29130A(SOP)	
	S-2914A	
	S-2914A(SOP)	
	S-2922A	
	S-2922A(SOP)	
<u>SGS-THOMSON(ST)</u>	GAL16V8-20	
	GAL16V8-25	
	GAL16V8A-10	
	GAL16V8A-12	
	GAL16V8A-15	
	GAL20V8-20	
	GAL20V8-25	
	GAL20V8-30	
	GAL20V8-35	
	GAL20V8A-10	
	GAL20V8A-12	
	GAL20V8A-15	
	GAL22V10-25	
	GAL22V10	
	GAL6001	
	ST24C01	
	ST24C02A	
	ST24C04	
	ST24C08	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	ST24C16	
	ST24LC21	
	ST24E32D	
	ST24E64D	
	ST25C01	
	ST25C02A	
	ST25C04	
	ST25C08	
	ST25C16	
	ST25E32D	
	ST25E64D	
	ST62T10	
	ST62E/T20	
	ST62E/T25	
	ST62E/T60	
	ST62E/T65	
	M2716	
	M2716P	
	M2732	
	M2732AF	
	M2764	
	M2764A	
	M27C64A	
	M2764AP	
	M27128A	
	M27C160	
	M27256	
	M27C256	
	M27C256B	
	M27512	
	M27C512	
	M27V512	
	M27C513	
	M27C1000	
	M27C1001	
	M27V101	
	M27C1024	
	M27C2001	
	M27V201	
	*ST M27W101	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	M27W201(K)	
	M27W201(N)	
	*M27C202	LP-PLCC-MPU51
	M27C4001	
	M27V401	
	M27C4002	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	M27C801	
	M27V800(F)	
	M27V800(B)	
	M27V800(M)	
	M27V160(F)	
	M27V160(B)	
	M27V160(M)	
	M27C322	
	M2816	
	M28C64C	
	M28F256	
	M28F256A	
	M28F512	
	M28F101	
	M28F101A	
	M28F101B	
	M28F201	
	*M28F411	LP-TSOP-2XF008
	M28F420	
	*M29F040	LP-PLCC-1M32,LP-TSOP-32PIN
	*M29V040	LP-PLCC-1M32,LP-TSOP-32PIN
	M29F002T	
	M29F002NT	DIP
	*M29F200T	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*M29F200B	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*M29F400T	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*M29F400B	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*M29W400T	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*M29W400B	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*M29W800T	LP-TSOP-2XFX00,LP-PSOP-AM29F100
	*M29W800B	LP-TSOP-2XFX00
	M29W008T	
	M29W008B	
	ST34C02	
	MK48Z02	
	MK48Z08	
	MK48Z12	
	MK48Z18	
	M48Z30	
	M48Z32	
	M48Z35	
	M48Z58	
	MK48Z59	
	M48T59	
	ST9306	
	ST93C06	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	ST9346	
	ST93C46A	
	ST93C46C	
	ST93C46T	
	ST93CS46	
	ST93CS47	
	ST93C56	
	ST93CS56	
	ST93CS57	
	ST93C66	
	ST93CS66	
	ST93CS67	
	C46A6	
	C46CM6	
	Z86E11	
	Z86E21	
<u>SHARP</u>	LH2464	
	LH21256	
	*LH28F004SCHN	LP-PSOP-28F400A
	*LH28F004SCHT	LP-TSOP-2XF008
	*LH28F008SCN	LP-PSOP-28F400A
	*LH28F008SCT	LP-TSOP-2XF008
	*LH28F008SAT	LP-TSOP-2XF008
	*LH28F008SCHT	LP-TSOP-2XF008
	LH5763	
	LH5763J	
	LH5764	
	LH5764J	
	LH57127	
	LH57127J	
	LH57128	
	LH57128J	
	LH57256	
	LH57256J	
	LH64400	
<u>SIEMENS</u>	SDA2506	
	SLA24C04D	
	SLA24C04D3	
<u>Signetics</u>	PLUS16L8	
	PLUS16R4	
	PLUS16R6	
	PLUS16R8	
	PLUS20L8	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	PLUS20R4	
	PLUS20R6	
	PLUS20R8	
	27C64	
	27C64A	
	27128	
	27C128	
	27C256	
	27C512	
	27C010	
	27C040	
	27C210	
	27C240	
	82S23	
	82S123	
	82S126	
	82S129	
	82S130	
	82S131	
	82S135	
	82S136	
	82S137	
	82S146	
	82S147	
	82S180	
	82S181	
	82S184	
	82S185	
	82S190	
	82S191	
	82S195	
	82S321	
	82S2708	
	*P87C750	LP-DIP-87C751,LP-PLCC-87C751
<u>SMOS</u>	27C64H	
	27128H	
	27C256H	
<u>SONY</u>	CXK27C256	
	CXK27C512	
	CXK5864BP	
	CXK5864BSP	
	CXK5864BM	
	CXK58256	
	CXK58256P	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	CXK58256PF	
	CXK581000	
<u>SST</u>	SST27SF010	
	SST27VF040	
	SST28EE011	
	SST29EE020	
	SST28SF040	
	*SST 28SF040A	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	SST28VF040	
	*SST 28LF040	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	SST29EE512	
	SST29LE512	
	SST29EE010	
	SST29LE010	
	SST39SF512	
	SST39SF010	
	SST39SF020	
	*SST39VF020	DIP,LP-PLCC-1M32
	*SST39VF040	DIP,LP-PLCC-1M32
	*SST39VF512	PLCC-1M32,LP-TSOP-32PIN
	SST89C54	
	SST89C58	
	SST89C59	
<u>SyncMos</u>	SYNMOS F29C51001T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*F29C51002T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*F29C51002B	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*F29C51004T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*F29C51004T	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
<u>SYNERTEK</u>	SY2128	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
TEMIC	TSC87C51	
	TSC87C52	
	TSC87251G1	
	TS87C51RB2	DIP
	TS87C51RC2	DIP
	TS87C51RD2	DIP
TI	TIBPAL16L8	
	TIBPAL16L8-10	
	TIBPAL16R4	
	TIBPAL16R4-10	
	TIBPAL16R6	
	TIBPAL16R6-10	
	TIBPAL16R8	
	TIBPAL16R8-10	
	TIBPAL20L8	
	TIBPAL20L10	
	TIBPAL20R4	
	TIBPAL20R6	
	TIBPAL20R8	
	TIBPAL20X10	
	TIBPAL22V10	
	TIBPAL22VP10	
	TICPAL22V10	
	TMS2532	
	TMS2564	
	TMS2732	
	TMS2732A	
	TMS27P32A	
	TMS2764	
	TMS27C64	
	TMS27P64	
	TMS27128	
	TMS27C128	
	TMS27PC128	
	TMS27C256	
	TMS27PC256	
	TMS27C512	
	TMS27PC512	
	TMS27C010	
	TMS27C010A	
	TMS27PC010A	
	TMS27C020	
	TMS27PC020	
	TMS27C040	
	TMS27PC040	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	TMS27C210	
	TMS27C210A	
	TMS27PC210A	
	TMS27C240	
	TMS27PC240	
	TMS28F512	
	TMS28F512A	
	TMS28F010	
	TMS28F010B	
	TMS28F020	
	*TMS28F400BZB	LP-PSOP-PA28F400
	*TMS28F400BZT	LP-PSOP-PA28F400
	18SA030	
	24S10	
	24SA10	
	24S41	
	24SA41	
	24L42	
	24LA42	
	24S81	
	24SA81	
	28S42	
	28SA42	
	28S86	
	28SA86	
	28L86	
	28S166	
	28L166	
	28S2708	
	TMS4016	
	TMS4164	
	TMS4464	
	TMS4256	
	TMS44400	
	TMS44100	
	*TMS320E15	LP-DIP-TMS320,LP-PLCC-TMS320
	*TMS320E17	LP-DIP-TMS320,LP-PLCC-TMS320
	*TMS320P17	LP-DIP-TMS320,LP-PLCC-TMS320
<u>TOSHIBA</u>	8748	
	8749	
	8750	
	TC514256	
	TC511000	
	TC514400	
	TC514100	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	TC538200	
	TC5316200	
	TC5332202P	
	TC531000D	
	TC5565	
	TC541000AP/AF	
	TC541001AP/AF	
	TC54H1000AP/AF	
	TC54H1001AP/AF	
	TC54H1024AP/AF	
	TC544000AP/AF	
	TC544200P/F	
	TC571000D/AD	
	TC571001D/AD	
	TC57H1000AD	
	TC57H1001AD	
	TC57H1024/AD	
	TC57C1025A	
	TC57H1025AD	
	TC574000D/AD	
	TC574200D	
	TC574096/D	
	TC578200D	
	TC5716200D	
	*TC5816AFT	LP-TSOPII-TC5816AFT
	TMM2016	
	TMM24512P	
	TMM2732	
	TMM2732A	
	TMM2732D	
	TMM2764	
	TMM2764D/DI	
	TMM2764AD/ADI	
	TMM2764AP	
	TMM27128	
	TMM27128AD/ADI	
	TMM27128AP	
	TMM27128D	
	TMM27256A	
	TMM27256D	
	TMM27512D/DI	
	TMM4164	
	TMM41464	
	TMM41256	
	TMM54256P	
	TMM54256AP	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	TMM57256	
	TMM57256AD	
	*TMP47P1638V	LP-SDIP-TMP47P1638V
	*TMP47P201VP	LP-DIP-TMP47P201VP
	*TMP47P241VN	LP-DIP-TMP47P241VN
	*TMP47P400VN	LP-SDIP-TMP47P400VN
	*TMP47P422VN	LP-SDIP-TMP47P422VN
	*TMP47P443VN	LP-SDIP-TMP47P443VN
	*TMP47P800N	LP-SDIP-TMP87P844
	*TMP47P853V	LP-SDIP-TMP47P853VN
	*TMP87P808M	LP-SOP-TMP87P808M
	*TMP87P844N	LP-SDIP-TMP87P844N
<u>ITL</u>	7400	
	7401	
	7402	
	7403	
	7404	
	7405	
	7406	
	7407	
	7408	
	7409	
	7410	
	7411	
	7412	
	7413	
	7414	
	7415	
	7416	
	7417	
	7418	
	7419	
	7421	
	7422	
	7423	
	7425	
	7426	
	7427	
	7428	
	7430	
	7432	
	7433	
	7437	
	7438	
	7440	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	7442	
	7443	
	7444	
	7445	
	7446	
	7447	
	7448	
	7449	
	7450	
	74LS51	
	7452	
	7453	
	74H54N	
	74LS55N	
	7460	
	7464	
	7465	
	7470	
	7472	
	7473	
	7474	
	7475	
	74LS76	
	7477	
	7478	
	7480	
	7482	
	7483	
	7485	
	7486	
	7487	
	7490	
	7491	
	7492	
	7493	
	7494	
	7495	
	7496	
	74LS96	
	74106	
	74107	
	74109	
	74110	
	74111	
	74112	
	74113	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	74114	
	74116	
	74125	
	74126	
	74128	
	74132	
	74133	
	74134	
	74135	
	74136	
	74137	
	74138	
	74139	
	74140	
	74141	
	74142	
	74145	
	74147	
	74148	
	74150	
	74151	
	74152	
	74153	
	74154	
	74155	
	74156	
	74157	
	74158	
	74159	
	74160	
	74161	
	74162	
	74163	
	74163A	
	74164	
	74165	
	74166	
	74170	
	74173	
	74174	
	74175	
	74179	
	74180	
	74181	
	74182	
	74183	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	74184	
	74185	
	74190	
	74191	
	74192	
	74193	
	74194	
	74195	
	74196	
	74197	
	74198	
	74199	
	74240	
	74241	
	74242	
	74243	
	74244	
	74245	
	74247	
	74248	
	74249	
	74251	
	74253	
	74257	
	74258	
	74259	
	74260	
	74265	
	74266	
	74273	
	74276	
	74279	
	74280	
	74283	
	74290	
	74293	
	74298	
	74299	
	74323	
	74348	
	74351	
	74352	
	74353	
	74365	
	74366	
	74367	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	74368	
	74373	
	74374	
	74375	
	74377	
	74377N	
	74378	
	74379	
	74386	
	74390	
	74393	
	74395	
	74399	
	74412	
	74465	
	74490	
	74541	
	74540	
	74573	
	74574	
	74597	
	74640	
	74641	
	74642	
	74643	
	74644	
	74645	
	74670	
	74682	
	74688	
	74804	
	74805	
	74808	
	74832	
	74874	
	741004	
	741035	
	741244	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
UMC	8748	
	8748H	
	UM23C8100	
	UM23C16100A	
	UM23C32100A	
	UM2732	
	UM2764	
	UM6116	
	UM6164	
	UM62256	
	*UM68P60	LP-DIP-UM68P60

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>VITELIC</u>	V51C64	
	V53C464	
	V53C256	
	V53C258	
	V61C16	
	V62C64	
<u>VLSI</u>	VT27C64	
	VT27C128	
	VT27C256	
	VT27C512	
	28H64	
	28HC64	
	VP16V8	
	VP20V8	

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
Winbond	W2416	
	W2465	
	W24257	
	W24512	
	W27E256	
	W27E257	
	W27C257	
	W27E512	
	W27C512	
	W27E512X	
	W27E010	
	W27F256	
	W27F512	
	W27F010	
	W27C010	
	W27C010S	
	W27C010P	
	W27C020	
	W27C020P	
	W27E040	
	W27E040P	
	W27E040T	
	W27E040S	
	W29C101	
	W29C102	DIP
	*W29C102P	LP-PLCC-44-MPU51
	*W29F102P	LP-PLCC-44-MPU51
	W29C020	
	W29C040	
	W29EE512	
	W29EE011	
	*W49F002U	DIP,LP-PLCC-1M32,LP-TSOP-32PIN
	*W77E58	DIP,LP-PLCC-MPU51
	W78E354	
	*W78E354-PLCC68	LP-PLCC-W78E354LC68
	W78E51	
	W78E51B	DIP
	W78E52	
	W78E52B	DIP
	W78LE52	DIP
	*W78LE52P	LP-PLCC-MPU51
	W78E54	
	W78E58	
	*W78E516	DIP,LP-PLCC-MPU51
	*W78E62	DIP,LP-PLCC-MPU51,LP-PQFP-44PIN

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>WSI</u>	WS27C64FM	
	WS27C128FM	
	WS2ZC256L	
	WS27C256F	
	WS27C256FM	
	WS27C512F	
	WS57C64F	
	WS57C128F	
	WS57C128FB	
	WS57C256F	
	WS27C010F	
	WS27C010L	
	*PSD301	LP-PLCC-PSD3XX
	*PSD302	LP-PLCC-PSD3XX
	*PSD303	LP-PLCC-PSD3XX
	*PSD311	LP-PLCC-PSD3XX
	*PSD312	LP-PLCC-PSD3XX
	*PSD313	LP-PLCC-PSD3XX

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
<u>XICOR</u>	X2210/I/M	
	X2212/I/M	
	X24C00	
	X24C01	
	X24C01A	
	X2402	
	X24C02	
	X2404	
	X24C04	
	X24C08	
	X24C16	
	X2444/I/M/P	
	X24C44/I/P	
	X24164	
	*X24645	LP-SOP-16PIN
	X2804A	
	X2804AI	
	X2804AP	
	X2816A	
	X2816AP	
	X2864A	
	X28256	
	X28C256	
<u>XILINX</u>	XC1718D	
	XC1718L	
	XC1736A	
	XC1736D	
	XC1765D	
	XC1765L	
	XC17128D	
	XC17128L	
	XC17256D	
	XC17256L	
	*XC7318	LP-PLCC-XC7354LC44
	*XC7318A	LP-PLCC-XC7354LC44
	*XC7318B	LP-PLCC-XC7354LC44
	*XC7336	LP-PLCC-XC7354LC44
	*XC7336A	LP-PLCC-XC7354LC44
	*XC7336B	LP-PLCC-XC7354LC44
	*XC7336Q	LP-PLCC-XC7354LC44
	*XC7354-PLCC44	LP-PLCC-XC7354LC44
	*XC7354-PLCC68	LP-PLCC-XC7354LC68
	*XC7372-PLCC68	LP-PLCC-XC7372LC68
	*XC73108PLCC84	LP-PLCC-XC73108LC84
	*XC9536VQ44	LP-VQFP-XC7336VQ44

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
	*XC9536PC44	LP-PLCC-XC9536LC44
	*XC9572PC44	LP-PLCC-XC9536LC44
	*XC9572PC84	LP-PLCC-XC95108LC84
	*XC9572TQ100	LP-TQFP-XC95108TQ100
	*XC9572PQ100	LP-PQFP-XC95108PQ100
	*XC95108PC84	LP-PLCC-XC95108LC84
	*XC95108PQ100	LP-PQFP-XC95108PQ100
	*XC95144PQ100	LP-PQFP-XC95108PQ100

LEAPER-10 Devices List

MENUFACTURE	DEVICE	ADAPTOR
Zilog	Z86E02	
	Z86E02-SL1925	
	Z86E03	
	Z86E04(OLD)	
	Z86E04-SL186X	
	Z86E06	
	Z86E08(OLD)	
	Z86E08-SL186X	
	Z86E21	
	Z86E30(OLD)	
	Z86E30-SL187X	
	Z86E31(OLD)	
	Z86E31-SL187X	
	*Z86E40	LP-DIP-Z86E40,LP-PLCC-Z86E40